
BT Quantum

Quick Reference Guide BT 8528 Digital Telephone



BT 8528 Digital Phone



1	Handset
2	Display
3	Ring/Message Indicator
4	Feature Keys
5	Dialpad
6	Navigation Keys
7	Programmable Keys
8	External Speaker

Handset: The handset is hearing aid compatible (HAC). When using headset or in Hands-free mode, you need not use the handset.

Display: Viewing area for using features and identifying callers.

Ring/Message Indicator: Flashes to show call, message and feature activity.

Flashing	An incoming call or Auto Answer activated
On	On a call or using a feature.
Off	Telephone is idle.

 $\textbf{Feature Keys:} \ \textbf{Provide quick access to commonly used features.}$

Key	Feature
↓ Up Down	Volume control for the ringer, handset, and speaker. Adjust ringer volume while phone is ringing. Adjust handset or speaker volume while using handset or speaker.
◄) Hands-free	Press to activate Hands-free mode (speakerphone).
A Mute	Press to temporarily turn off microphone during a call.
Directory	Accesses the system speed dial list. Select number index and lift handset to dial.
⊗ Cancel	Cancel key when handset lifted. Left/backspace when entering dialpad text.

Key	Feature
123 Redial	Calls the last external number dialled.
△a Hold	Places the current external call on hold.
~ Recall	Recall Key / Transfer, Conference (See Feature Code table)
№ Message	Connects to your voice mailbox and lights to indicate message waiting. Toggles between Alpha Mode and Numeric Mode when entering dialpad characters.

Dialpad: Use to dial phone numbers, enter feature codes, and enter characters when using features that require text input.

Navigation Keys: Use to scroll through the System and Individual Speed Dial Directories.

Programmable Keys: 14 programmable keys.

External Speaker: Provides audio for Hands-free calls and background music.

Using your BT 8528 Phone

Placing Emergency Calls

Select a line or lift the handset and dial 9

Dial emergency number: 999 or 112

Answering Calls

Lift the handset, or Press **Hands-free** to answer a call with a headset or in Hands-free mode.

Placing Internal Calls

Lift handset or Press **Hands-free** Dial extension number.

Placing External Calls

Lift handset or Press Hands-free Dial Outgoing Call access code (9 by default) Dial the number.

Redialling External Numbers

With or without lifting handset Press **Redial** or lift the handset and Dial **77**.

Transferring Calls to Extensions

While on a call

Press Recall
Dial extension number
Or
Dial Outgoing Call access code

Dial Outgoing Call access code (9 by default) and external number. Wait for answer, announce call, and

hang up. If no answer Press **Recall** to return to call. Or Hang up to transfer call and disconnect call from your phone.

Programming Keys

Lift the handset and dial 727
Select the key to be programmed
Dial Feature Code or number to be
assigned to the key
Hang up phone to finish
programming.

(See Feature Code Table for list of codes.)

Using Do-Not-Disturb

To activate or cancel: Lift the handset and dial **736** When ON, callers receive busy signal.

Personal Speed Dial

Storing Speed Dial Numbers

Without lifting the handset dial **75**Select location for number (01 – 50)
Enter number followed by #
Enter name followed by #
Press the "Programme key" to exit

Calling Speed Dial Numbers

Dial 74

Dial location of number (01 – 50) Lift handset or Press **Hands-free** to dial number.

FMC (Fixed Mobile Convergence)

Mobile Ringing with FMC

To turn On/Off simultaneous ringing of extension and mobile phones: Lift handset and dial **790**

Note: extension number must first be associated with mobile number through system programming.

Call Toggling with FMC

When Mobile Ringing is enabled:

If call answered on extension phone Press **Recall** and Dial **788** to toggle to mobile phone.

If call answered on mobile phone Dial **787** to toggle to extension.

Playing and Recording Voicemail Messages

Extensions must be set up with a Voice Mailbox before using Voicemail.

With handset on phone Press **Message** Dial extension, password and #. Follow prompts as described in following table.

While listening to the Greeting

Dial	
1	Begin playback at first message.
01	Change outgoing greeting.
05	Change Voicemail Password.

After message playback begins

Dial	
0	Pause Playback.
4	Go back to previous message.
5	Go back to start of message.
6	Play the next message.
7	Erase the message
8	Forward message to another

Dial	
	extension.
*	Go back 10 seconds.
#	Go forward 10 seconds.
32	Return Call. Automatically make a call to caller who left the message. Dial the code after the message is finished. (Not applicable with remote mailbox access)

Diverting Calls

Lift the handset and dial **732** to Divert all Calls

To divert internally, dial extension number followed by #.

Or

To divert externally, dial Outgoing Call access code (9 by default) and external number followed by #. Dial 732 followed by # to cancel See table for other Divert Codes.

For more information about using phone features and programming feature keys, refer to your System Administrator for copies of the *BT Quantum User Guide* and *BT Quantum Administration Guide*.

Commonly Used Feature Codes Note: **R = Recall** Key

Account Code: before call	796
Account Code: while on a call	R797
System Voicemail On/Off	737
Auto Answer On/Off	705
Background Music	706
Call Pick-up (incoming only)	726 XXX
Call toggle: FMC. Retrieve call	787
Call toggle: FMC. Send call	R788
CLIR activation	724
Conference	R3
Divert All	732XXX#
Divert on Busy	733XXX#
Divert on No Answer	734XXX#
Do Not Disturb: set/cancel	736
Door Open – when not on a call	731
Door Open – when on a call	R731
Extension Groups 1-10	180-189
Extension Groups 11-20	190-199
Extension Groups 11	0
Extension Lock: change code	714XXXYYY
Extension Lock: lock/unlock	713 XXX
Extension numbering (default)	201-248
External Call Hold	R
External Call Hold: Retrieve	719
Follow Me (+ personal code)	735
Forward Recall	R728
Group Divert All Calls	792(180- 199)XXX#
Group Divert on Busy	793(180- 199)XXX#
Group Divert on No Answer	794(180- 199)XXX#
Key programming	727
Log In to all Groups	723*1

Note: K - Recall Key	
Log out all groups	7231*0
Log in/Log out of hunt group	723 XX
Line Access – Group 1	9
Line Access Groups 2- 11	760 – 769
Night Service (Ext. 201 only)	738
PA announcement	720
Page All Systemphones	716
Page All	730
Page: Voice Call	715
Paired Extensions	702XXX#
Mobile Ringing On/Off	790
Mobile Ringing On/Off times (+ HHMMHHMM)	791
Mobile Ringing Weekend Svc.	795
Park Calls	R722 (1-5)
Pick up parked call	712 (1-5)
Redial	77
Reminder Call	718HHMM
Reminder Call Cancel	718 *
Reset telephone	739
Return and Hold in 2-Call handling	R2
Return and Release in 2- Call handling	R1
Ring Back	R5
Ring Tone change	703(Up and Down key)
Room Monitor	798
Speed Dial Access (Personal)	7401-7450
Speed Dial Programme (Pers)	7501-7550
System Speed Dial Access	4001-4999
Voicemail	*

Safety Instructions and Precautions

WARNING: Do not connect directly to the public switched telephone network (PSTN). Any connection of this phone to an off premise application, an out of plant application, any other exposed plant application, or to any equipment other than the intended application may result in a safety hazard, and/or defective operation, and/or equipment damage. 'Exposed Plant' means where any portion of the circuit is subject to accidental contact with electric lighting or power conductors operating at a voltage exceeding 300 V between conductors or is subject to lightning strikes.

WARNING: The handset supplied with the phone shall not be substituted with any other handset. Use of other handsets with this phone may have the potential to cause hearing loss in the event of a lightening strike on the outside plant wiring.

When you use your phone equipment, basic safety precautions should always be followed to reduce the risk of fire, electric shock and injury to persons, including the following:

- Do not use this product near water, for example, near a bathtub, washbowl, kitchen sink or laundry tub, in a wet basement or near a swimming pool.
- Avoid using a phone (other than a cordless type) during an electrical storm. There may be a remote risk of electric shock from lightning.
- Do not use the phone to report a gas leak in the vicinity of a leak.

Maintenance and Repair: There are no user serviceable parts inside the phones. For repairs, return the phone to BT.

These notices may appear on the product or in the technical documentation:

DANGER	Danger indicates an imminently hazardous situation which, if not avoided, will result in death or serious injury.
WARNING	Warning indicates a potentially hazardous situation which, if not avoided, could result in death or serious injury.
CAUTION	Caution indicates a potentially hazardous situation which, if not avoided, may result in minor or moderate injury and/or damage to the equipment or property.

This symbol may appear on the product:



The exclamation point within an equilateral triangle indicates that important operating and maintenance (servicing) instructions are included in the literature accompanying the product.



The CE marking on this equipment indicates compliance with the following: This device confirms to Directive 1999/5/EC on Radio Equipment and Telecommunications Terminal equipment as adopted by the European Parliament



The telecommunications services described in this publication are subject to availability and may be modified from time to time. Services and equipment are provided subject to British Telecommunications plc's respective standard conditions of contract.

Nothing in this publication forms any part of any contract.

© British Telecommunications plc 2011.

Registered Office: 81 Newgate Street, London EC1A 7AJ. Registered in England No: 1800000.

Printed in China.

Part No. 57011418CN DOC BT 8528 Quick Reference Guide Rev4 Printed on paper which meets international environmental standards