



# BT Versatility V Telephone

## User Guide



## Feature List

- 3 Line 16 Digit and 16 Character Display
- 99 Number Calls Log with Repeat Call Counter
- One-Touch Callback from the Calls Log
- New Call/Message Waiting Indicators
- Monitor
- 7 One-Touch Memories
- Dialed Number Display
- Last Number Redial
- Hearing Aid Compatible
- Ringer High/Low/Off Selector
- Ringer Tone R1/R2 Selector
- Handset Volume High/Normal Selector
- Store/Recall/Redial/Callback and Monitor Buttons

## Getting Started

### • Inserting the Batteries

To use the Caller Display function on this telephone you will need to use 4 x AAA (1.5V) batteries. Before inserting the batteries please make sure that the telephone line cord is disconnected.

1. Use a screwdriver or other flat tool to open the battery door underneath the product.
2. Insert the 4 x AAA (1.5V) batteries, making sure that each one is the correct way around.
3. Close the battery compartment door securely and plug in the telephone line cord.

Note: If the Low Battery icon '🔋' appears on the display, the batteries must be replaced to gain full use of all the product features.

### • Language Setting

1. Press and hold the Review ▲ and ▼ buttons simultaneously for 4 seconds.
2. Press the Review ▲ or ▼ button to scroll through the language options
3. Press the 'Store' button to confirm the language selection.

### • Contrast Setting

You will be prompted to set the Contrast immediately after you have set the product 'Language' setting as above.

1. Press the Review ▲ or ▼ button to scroll through the contrast settings.
2. Press the 'Store' button to confirm the contrast selection.

### • Time and Date Setting

You will be prompted to set the Time and Date immediately after you have set the product 'Contrast' setting as above.

1. Press the ▲ or ▼ combined with digits from the keypad for the correct time and date.
2. Press the 'Store' button to confirm the setting.

### • Storing a Number in the One-Touch Memories

When storing numbers in the memory locations, please keep the telephone handset on hook.

1. Press the 'Store' button
2. Enter the numbers to be stored, using the keypad
3. Press the 'Store' button again
4. Press the memory location button where the number is to be stored (M1 – M7).

### • Dialling a Stored Number

1. Pick up the handset or press 'Monitor'.
2. Press the relevant one-touch memory button (M1-M7)

### • Receiving and Storing Calls in the Calls Log

This product has a 99 number Caller Display Log and will store the Number, Time and Date of your calls.

An 'X' will be displayed for Repeat Calls Log Entries.

When the Calls Log is full, the oldest call record will automatically be replaced by a new Call.

• **Viewing Calls in the Calls Log**

Press the ▲ Review button to view each new call. When you have viewed all the new calls, 'END OF LIST' will be displayed.

Press the ▼ Review button to view the previous call record.

• **Call Back from the Calls Log**

1. Press the ▲ or ▼ button to search for the entry you wish to Call Back.
2. Lift up the handset or press 'Monitor'.
3. Press the 'CALL BACK' button.

• **Clear Button**

1. Press the ▲ or ▼ button to search for the entry you wish to delete in the Calls Log.
2. Press the 'Clear' button twice to delete the Call Record.
3. To delete all the entries in the calls log, press and hold the 'Clear' button for approximately 4 seconds, then release the button. Press the 'Clear' button again and all the entries will be deleted.

• **Message Waiting**

If a caller has left a voicemail message for you the text 'NEW MESSAGE' will appear on the display and the New / Msg LED will flash.

• **Redial/Pause Button**

To redial the last number you dialled.



1. Pick up the Handset or press 'Monitor'.
2. Press the 'Redial' button.

• **Recall Button**

Press the 'Recall' button to use services such as Call Waiting and Call Transfer.

**Special Message Indications**

The following special message indicators show the current status of the product:

NO CALLS	The Caller Display log is empty
UNAVAILABLE	The call has originated from another network which does not support the sending of Caller Display information.
WITHHELD	The caller has withheld their Caller Display information.
END OF LIST	There are no new Calls to be viewed.
X	Repeat Call Indicator
	Low Battery Indicator
	New Call Indicator

## **R&TTE Directive**

Hereby, TMX declares that this 'BT Versatility Telephone' is in compliance with the essential requirements and other relevant provisions of directive 199/S/EC.

A copy of the declaration of conformance for the 'BT Versatility Telephone' is available from TMX, Alpha Business Park, 28 Whitehouse Road, Ipswich IP1 5LT



The telecommunications services described in this publication are subject to availability and may be modified from time to time. Services and equipment are provided subject to British Telecommunications plc's respective standard conditions of contract.

Nothing in this publication forms any part of any contract.

© British Telecommunications plc 2003  
Registered office: 81 Newgate Street, London EC1A 7AJ  
Registered in England No. 1800000

Designed by H&P Graphics Limited  
Printed in Ireland

**PHME 42394/01/04**  
Part No. 2722.31000-2

Printed on paper which meets international environmental standards