

BT Versatility

Voice Messaging

To access your Voice Mailbox Enter Your Extension Number Enter Your Password Key	Key 711 #
When listening to the greeting Record Greeting Check Greeting	91 92
To access the Answering Machine/ System VM Box Key Key	711 0
Answering Machine Password Key	#

When listening to the greeting	Key
Record Greeting Check Greeting Delete Greeting To start playing messages	91 92 93 1
When replaying messages:	
Pause Save and go to next Erase and go to next Go to start of message Go to previous message Erase all messages Go back 10 Secs. Go forward 10 Secs. Forward the message Return Call*	# 2 3 4 5 6 7 8 9
*Not available when accessing the Voice Messaging externally	
PHME 42392/01/04	
Part No. 2735.31000 -2	