



Polycom VVX 500 and 601

A guide to using your phone with Cloud Voice.



What's in this guide

What's in the box	3
Got everything?	3
Let's get started	4
Set your phone up	4
Get connected	4
Check you're connected to Cloud Voice	5
Connect your headset	5
USB ports	5
Getting to know your phone	6
Touchscreen	6
Cleaning your touchscreen	6
Phone display – views	7
Using your phone	9
Time and date	9
Making calls	9
Answering calls	9
Transferring calls	9
Ending calls	9
Conference calls	9
Do not disturb	10
Favourites	10
Recent call list	10
Saving recent callers	10
Contact directory	10
Changing ring tone	11
Update your settings	11
Checking your voicemail	11
General info	12

General info

Need help?

If you have any problems with your phone, call us on **0800 389 0537** and we'll be happy to help.

Calling 999 or 112

Your Cloud Voice number is registered to a specific address, so when you make a **999** or **112** call from your phone number, that's the address the emergency services will see.


If you use Cloud Voice at a different address, the registered address won't automatically change. So if your work location changes, please let your administrator know so they can update your registered address.

What's in the box


We're here to help you get the best out of your new phone. So let's get set up. Just follow the instructions below.

Got everything?


- IP phone
- Handset
- Handset cord
- Mains power adapter
- Ethernet cable
- Phone stand
- Quick start user guide




Phone




Handset and Cord



Quick Start Guide



Network Cable



Phone Stand


Let's get started

Set up your phone

Unpack it and turn it upside down so you can see the ports. Then slot the phone stand into one of the slots, depending on the angle you want.

Get connected

Here's how to connect your cables.



Check you're set up on Cloud Voice

Your phone comes with everything you need to get set up on Cloud Voice.

- Once your phone is connected to the network, it will update its firmware. This might take some time, so please be patient.
- Once it's finished, it'll show this symbol:



If something has gone wrong, you'll see this symbol:




If this happens, just give us a call on **0800 389 0537** and we'll be able to help.

Once everything is updated and ready to go, your Cloud Voice number will show on the screen.


During future firmware updates, your phone might run through these same steps.

Your Cloud Voice number




Connect your headset

Your phone works with wired headsets, which usually connect through the RJ-9 port shown below. It also works with electronic hookswitch headsets, which tend to connect with the RJ-9 and serial ports. To add a headset, just follow the instructions that come with it.



Getting to know your phone

Phone features and keys



Touchscreen

VVX500 and 601 phones have a touch-sensitive screen

Tap the screen to select the function that you need; to scroll, swipe your finger up, down, right or left on the screen.

Cleaning the touchscreen

If you need to clean your touchscreen, do this with a dry microfibre cloth. You can get these from the supermarket or an office supply store.

Before you wipe your screen, you'll need to disable it. To do this:

- Tap **settings** from home view, then tap **basic > screen clean**.
- You can now wipe the glass with your microfibre cloth.

To answer a call while the touchscreen is disabled, pick up the handset or press **answer**.

To enable the touchscreen again, press any key on your phone.






Phone display – views

Your phone has three main views: **home**, **calls** and **lines**. Lines is your default display. You can switch to the home or lines views whenever you want, too.

- To get to the home view, press the **home** key.
- To change to the **lines** view, press the **home** key again.
- To get back to home, press the **home** key one more time.
- When you're making or receiving a call, you'll also see the **calls** view.
- You can switch between the three screens whenever you want using the home key.

Home view

You can get to the different phone functions from the **home** view. Just use the navigation key to scroll through the options, then press the **Select** key when you find the one you want.

New Call	Brings up the dialpad so you can make a new call	
Messages	Checks your voicemail	
Directories	Takes you to your contact directory and recent calls list	
Settings	Lets you change your phone's settings and customise ringtones	
Applications	Lets you use web apps like Google	

Lines view

The **lines** view is your phone's default display. It shows your phone lines, your favourite contacts and the different options for your soft keys. You can also get to your voicemail from here by tapping the **envelope** icon.



Call view

When you make or receive a call, you'll see the **call** view. It shows you the phone number, the call length and how many calls you've got in progress.


Calls are colour coded depending on what's happening:

Dark green	The call you're on
Dark blue	Any incoming or held calls
Bright green	An active call that's been highlighted
Bright blue	An incoming or held call that's been highlighted

If you want to use the soft key features, just highlight the call. To do this, tap the call and look at the display directly above each soft key for your options.

The soft keys will let you:

Hold	Put a call on hold (there's default hold music)
End Call	Finish the current call using the soft key
Transfer	Pass the call on to someone else's extension
Confrnc	Add your call to a conference



Using your phone

Time and date

Your phone's time and date is set by Cloud Voice, but you can change the format by going to **settings** and updating your preferences.

Making calls

When you're ready to dial, pick up the handset, press **speakerphone** (or **headset** if you're using one) and enter the phone number. Then press the **new calls** key.

If you're in the lines view, tap the phone line, enter the number and press **new call**.

If you're in the home view, tap **new call**, enter the phone number and press **new call**.

Answering calls

To pick up a call, press the **answer** soft key and pick up the handset, or press **speakerphone**. If you're using a headset, press the **headset** key.

If you're already on a call when you receive another one, press the **answer** soft key and the call you're on will be put on hold. Both calls will show on your display. You can go back to the first call by selecting that call on the display and pressing the **resume** soft key.

Transferring calls

To transfer a call, first press the **transfer** soft key. Then dial the number the call is being transferred to and press the **send** soft key. To forward the call straight away, press **transfer**. If you want to announce the call beforehand, wait until the person picks up and then press **transfer** to connect it.

Ending calls

You can end a call in four different ways. Either put your phone down, press **speakerphone**, press the **headset** key if you're using one, or press the **end call** soft key.

To end a held call, navigate to **calls** view and highlight the held call. Press **resume**, then press **end call**.

Conference calls

If you want to set up a conference call, dial the first person then press the **more** soft key and select **confrnc**.

Dial and connect with the second person and press **confrnc** again.

While you're on a conference call with the lines or calls view, you can:

Press the **hold** soft key to put everyone on hold

Press **end call** to leave the call, but keep the others connected

Press the **split** soft key to end the conference and put everyone on hold.

Do not disturb

If you need a few minutes without interruptions, you can use do not disturb to send callers straight to voicemail.

To activate do not disturb, go to the **home** view, tap **settings, features** then **do not disturb** and press the **enable** soft key.

To disable do not disturb, go to the **home** view, tap **settings, features** then **do not disturb** and press the **disable** soft key.

Favourites

Your favourites are the people you call most often. Their numbers will show in your **favourites** list and in the **lines** view.

To see your favourites list, press **new call** from home view and then **favourites**. To add someone to your favourites, go to your contact directory and use the **select key** to select them. Press **add to favourites**, then **yes** to confirm.

To dial a favourite, just tap their contact details from the lines view or from the favourites list.

To change the order of your favourites, update the person's favourites index number in the contact directory to move them up or down the list.

Recent calls list

To view your latest calls, tap **new call** from home view, then choose **recent**. Once you're in the recent list, you can tap the **sort and order** key to sort and order calls, tap the **order calls** key to display only certain calls, or tap **call record** to speak to the person. You can also use the recent calls key from the home, lines or calls view.

Saving recent callers to your directory

If you'd like to save a new number from your recent calls, tap next to the call record and press **save**. Enter any extra details and press **save** again.

Contact directory

Your contact directory is managed by Cloud Voice. Have a look at the user feature guide to find out more.

You can also manage your contacts from your phone. To do this, select **directories** from home view, highlight **contact directory**.

- To add them to your favourites list, enter a favourite index number.
- If you need to update any of their details, select the contact, tap the **edit** soft key and then press **save**.
- To delete a contact from the directory, select them and then press **delete**. Press **yes** to confirm.
- To search the contact directory, press the **search** soft key, enter your search term and then press **search**.
- To call one of your contacts, highlight their details using the **select** key and press **dial**.

Changing your ringtone

If you'd like to change your ringtone, select **settings** from the home view, go to **basic > ring type**. Choose the ringtone you want and then press **back**.

To set a ringtone for a contact, choose them from your contact directory, press the **edit** soft key, update the ring tone and press **save**.

Update your phone settings

Sometimes your phone settings might need to be updated. To do this:

- Tap **settings** from home view, and choose **basic > update configuration**.
- You'll see a message saying 'Are you sure?'
- To go ahead, choose **Yes**.

Your phone might need to restart, depending on the settings you've changed.

Listening to your voicemail

If you see the envelope icon on your screen, you've got voicemail. Go to messages from the home view and select **message centre**. You'll be able to see how many messages you've got in your mailbox. To listen to your messages, tap **connect** and follow the instructions.

General info

999 or 112 emergency calls

- Your Cloud Voice number is registered to a specific address, so when you make a 999 or 112 call from your phone number, that's the address the emergency services will see.
- If you use Cloud Voice at a different address, the registered address won't automatically change. So if your work location changes, please let your administrator know so they can update your registered address.
- You might not be able to make 999 or 112 calls if there's a power or network failure, or you're using the service from an app or mobile phone.

Headsets you can use

Your VVX 500 and 601 phones works with the following Jabra and Plantronic headsets:

Jabra

Corded headsets:

Jabra Biz 2400 headsets with GN 1200 Quick Disconnect Cable – setting 1

Cordless headsets:

Jabra Pro 920 with Jabra Polycom EHS adapter

Plantronics

Corded headsets:

SupraPlus HW251N / HW261N and EncorePro HW710N / HW720N with U10p cable

Cordless headsets:

CS504A Convertible Dect with APP-51 (Polycom EHS Cable)

Safety information

- Opening your handset or the base of your phone could be dangerous. If your phone needs to be repaired, call us on 0800 389 0537 and we'll be able to help.

Looking after your phone

- Clean your phone and base with a damp (not wet) cloth or an anti-static wipe. Never use household polish as this could damage your phone. And don't use a dry cloth as this could cause a static shock.
- Don't expose your phone to direct sunlight.
- Make sure your phone is on a dry, flat surface, not on a carpet or anything which has fibres. Make sure it can always get a free flow of air over its surfaces.
- Don't expose your phone to water, and don't use it in damp or humid conditions like bathrooms.
- Don't expose your phone to fire, explosive or other hazardous conditions.
- If there's an electrical storm, there's a slight chance your phone might be damaged.

Getting rid of your phone



The symbol shown here and on your phone means your product is classed as electrical or electronic equipment. You shouldn't throw it away with other office waste.

The Waste of Electrical and Electronic Equipment (WEEE) Directive (2002/96/EC) has been put in place to recycle products in the best ways for the environment, making sure we manage anything that's hazardous and don't increase the amount of landfill we produce.

You should get in touch with your supplier to check the terms and conditions of your contract and make sure the phone isn't thrown away with other commercial waste.

Guarantee

Your phone is guaranteed for 12 months from the date you bought it. Your guarantee covers the repair or replacement of your phone or any of its parts (other than batteries) if they're faulty or below standard, or they break because of bad workmanship or materials. If your product is more than 28 days old, it might be replaced with a refurbished or repaired product.

The conditions of this guarantee are:

- The guarantee only applies to issues that arise during the 12 month guarantee period.
- You'll need to show us your proof of purchase.
- You'll need to return your phone to us according to our instructions
- We don't cover any faults or problems that are caused by accidents, misuse, fair wear and tear, neglect, or if you've tried to repair the equipment yourself.
- This guarantee won't affect your statutory rights.

Offices Worldwide

The services described in this publication are subject to availability and may be modified from time to time. Services and equipment are provided subject to British Telecommunications plc's respective standard conditions of contract. Nothing in this publication forms any part of any contract.

© British Telecommunications plc 2018. Registered office: 81 Newgate Street, London EC1A 7AJ. Registered in England No. 1800000.

RingCentral logo is a registered trademark of RingCentral, Inc. Polycom and VVX are trademarks of Polycom, Inc.